

CONTENTS



______ [PAGE 2] - CONTENTS

______ [PAGE 3] - WELCOME

_____ [PAGE 4] - MY OBI CAMPER

______ [PAGE 5] - VEHICLE IDENTIFICATION NUMBER

_____ [PAGE 6] - SPECIFICATIONS

______ [PAGE 7 to 9] - WARRANTY

_____ [PAGE 10] - SET UP



GRAVELER





WELCOME



Congratulations on your new Camper Trailer! We are thrilled that you have chosen an OBI Camper Trailer for all your outdoor adventures! We strive to provide excellent customer service to every customer. We have created this Owner User Manual to help you navigate and learn about your new Graveler Camper. We encourage each customer to review this Manual as an overview before your first outdoor adventure. If you have any questions regarding your Camper that are not in this manual, the Dealership that you purchased from, should be able to answer any questions you may have. We are happy to help you with any further questions if needed.

Getting familiar with your Camper as well as following instructions, understanding all Warning Labels, will help you become an expert with understanding how your Camper functions and how to take care of your Camper for years to come! We encourage you to Scan the QR Code located at the bottom of this page OR the inside on of your camper (add location) and have a hard copy kept in your Camper as a reference guide when you are exploring the outdoors.

Here at OBI, we standardize a high standard with each Camper that is Manufactured. From the beginning of being built to the time they get delivered, ensuring that each Camper goes through a in depth inspection before they leave our facility. The Dealership that you purchased from will also perform their own inspection before you take the unit home. We encourage you to discuss with your Dealer regarding any questions you may have, getting familiar with your Graveler, as well as understanding the tests/ inspections your Dealer has run to ensure that your Camper is working as it should.

If for any reason you suspect that your OBI Camper is not functioning properly, please reach out to your Dealership and discuss setting up an appointment to look at your Camper. If you are traveling and you run into a problem, please contact your Dealer first before any repairs are conducted Independently, to ensure that you will be covered under your Warranty.

For any appliances/ accessories, please refer to those appliance manuals for any support and warranty assistance.

The OBI Graveler Camper is designed for recreational use only. We encourage you to get familiar with the warranty for your trailer to ensure that your use falls in line with the intended usage covered under warranty. Usage outside of these terms could reduce or void your warranty. You can find all warranty information in this Owner User Manual.

If you have any questions about your OBI Graveler Camper, we are always happy to help! You can contact us at info@obicamper.com or call us at 877-949-4226.

We wish you a fun outdoors experience with your New Camper!









MY DBI CAMPER INFORMATION		
	OWNER INFORMATION	
	OWNER NAME -	
	OWNER ADDRESS -	
	UNIT INFORMATION	
	MODEL -	
	MODEL YEAR / BUILD DATE -	
	(V.I.N -	
	DRY WEIGHT -	
	GVWR -	
	TIRE SIZE -	
	COLD TIRE PRESSURE -	
	PURCHASE AND DEALER INFORMATION	
	PURCHASE DATE -	
	DEALERSHIP -	

PLEASE FILL OUT THE ABOVE FOR AND KEEP FOR YOUR RECORDS

40

GRAVELER



VEHICLE IDENTIFICATION NUMBER							
		GR	AVELE	R			
					DATE - / 2021		
	MANUFACTURED I GVWR GVWR FRONT	BY: OBI CONQUEROR CORP.	TIRES	RIMS			
	GAWR INTERM	COLD INFLATION PRESSURE	TIRES	RIMS			
	GAWR REAR	COLD INFLATION PRESSURE	TIRES	RIMS			
				DR MANUFACTURERS' IVD WHERE ICLE SAFETY STANDARDS, IN EFF			
	V.I.N XXXXXXXXX	XXXXXXXX		TYPE: POP-TOP TRAVEL TRAI	LER FD-329		

ALL OF OUR CAMPERS COME WITH AN INDIVIDUAL VEHICLE IDENTIFICATION NUMBER (VIN) BELOW FIND AN EXAMPLE OF THE VIN STICKER FOR YOUR CAMPER. This can be found on the inner frame of the tounge on your camper.





SPECIFICATIONS



WEIGHTS AND DIMENSIONS

MODEL - GRAVELER
COLOR - GREY
HEIGHT COLLAPSED - 7.125 FT
BOX LENGTH - 5.64 FT
OVERALL LENGTH - 13.0 FT
GROUND CLEARANCE - 2.0FT
TOUNGE WEIGHT - 308 LBS
DRY WEIGHT - 2336 LBS
GVWR - 3306 LBS

POWER

CHARGER - NOCO	
110V POWER - SHORELINE HOOKUP	
BATTERY - (2) 100 AH BATTERIES	

STORAGE

REAR MOUNTED SPARE
EXTERIOR LOCKING BOXES
FRONT MOUNT STORAGE BOX
21 GALLON CITY WATER TANK
REAR JERRY CAN HOLDERS

AMENITIES

SPACIOUS FORWARD ROOFTOP TENT
EXPANDABLE ANNEX TENT
PULL OUT KITCHEN WITH 2 BURNER STOVE
SINK WITH HOT / COLD FAUCET
SLIDE OUT REFRIGERATOR DRAWER
SHOWER SYSTEM
USER CONFIGURABLE MODULAR INTERIOR
LED INTERIOR LIGHTING
FRONT AND REAR WINCH
SEAFLO WATER PUMP



HITCHING / COUPLER

MCHITCH AUTOMATIC COUPLER















SUMMARY OF WARRANTY:

OBI/Conqueror Corporation warrants a limited manufactures warranty for every Camper to the first retail consumer for a period of five (5) years from the date of purchase under normal use and service for Chassis, Drawbar and Structure when used for its intended purpose of recreational travel and camping. All parts manufactured by OBI/Conqueror Corporation have a one (1) year warranty. Zips and mesh or screens are not covered. This warranty begins on the date the first retail consumer purchaser takes delivery. By purchasing a camper/caravan from OBI/Conqueror Corporation or its authorized dealers, you hereby agree to all terms and conditions of warranty.

validity of claims:

- Does not cover damage due to unauthorized modifications, misuse, abuse, incorrect assembly, improper and irregular maintenance or accident.
- Warranties are not transferable. If an item is sold to a third party by the original purchaser, then all warranties become null and void, and the original purchaser shall make no claims or be eligible for any claims on behalf of the new owner.
- Any vehicle used for commercial purposes.
- Does not cover normal wear and usage, such as fading or discoloration of soft goods (Tent, upholstery, drapes, screens, cushions, mattresses), fading or discoloration of wood, plastic or fiberglass components, tarnishing of aluminum or stainless-steel surfaces, tears, punctures, soiling, mildew, effects of moisture condensation inside the Camper, or mishandling, neglect, abuse, misuse, lightning or other acts of nature, or corrosive atmospheres which can result in rusting, oxidation or pitting.
- Minor imperfections, which do not affect the suitability of the Camper for its intended use.
- Normal and routine maintenance such as inspections, lubricating, adjustments, tightening of screws, tightening of lug nuts, scaling, cleaning, or damages arising from the failure to have maintenance performed or improper storage as outlined in the owner's manual and/or the component manuals.
- Wheel alignment or adjustments when caused by improper maintenance, loading or damage from road hazards, including off road travel, wheel damage or balancing, or damage resulting from tire failures.
- Costs incurred for onsite service, transportation of the Camper to a dealer or costs incurred as the result of the consumer's request to have repairs performed at a location other than an authorized dealership.
- Does not cover impact or damage to body or chassis. Soiling of fabrics and internal fitments
 from dust and other airborne substances. Water damage due to water crossings, movement or
 damage caused by dislodgement of appliances and fittings resulting from hard impact or heavy
 landings or severely rutted roads or tracks. General damage from misuse, rust, wheels and tires,
 paint and general consumables (bearings, light bulbs etc.) Damage due to condensation, normal
 wear and tear, exposure to elements, wear and tear when a camper/caravan has been used for
 commercial, rental, business or permanent living purposes. The Camper is designed only for its
 intended purpose of recreational camping and personal use. OBI/Conqueror Corporation does
 not warranty Campers used for commercial, rental, business or permanent living purposes.
- Tents are guaranteed to be in new merchantable condition at the time of purchase. A limited manufacturer's warranty period of one (1 year) applies to OBI/Conqueror Corporation canvas







components, poles and fittings. General wear and tear excepted. Zips and mesh or screens are not covered.

OBI/CONQUEROR CORPORATION'S RESPONSIBILITY:

Any part of the vehicle subject to warranty, which is found to be defective in material or workmanship, will be repaired or replaced at OBI/Conqueror Corporation option without charge to the customer for parts or labor.

HOW TO OBTAIN WARRANTY SERVICE:

In the event that a substantial defect in materials or workmanship is found to exist in parts warranted by OBI/Conqueror Corporation, OBI/Conqueror Corporation will bear the cost of the repair or replacement of such defective materials or workmanship, provided that the owner: (A) Notifies Dealer that unit was purchased from of the defect in a timely manner, (If you are traveling or have recently moved, contact the Dealer that unit was purchased from. (B) Follows instructions from OBI/Conqueror Corporation on how to get approved repairs. (OBI/Conqueror Corporation will determine if there is an authorized service center within reasonable distance of the owner. If there is not an authorized service center near the owner, the owner will be required to get two written estimates, from any local RV dealer or RV service station, for the required repairs.) (C) Schedules an appointment and promptly takes the vehicle to the authorized service center for necessary repairs. (D) Pays any freight or transportation costs, or import duties or fees involved. No action to enforce this warranty shall be commenced after expiration of the warranty period. If the above steps have been taken and the repairs still have not been made, the customer should contact OBI/Conqueror Corporation.

PURCHASER'S OBLIGATIONS:

Purchaser shall notify Dealer that unit was purchased from and deliver this vehicle for warranty service within a reasonable time after discovery of the defect, before the expiration of the warranty period. All incidental and consequential expenses incurred by Purchaser in obtaining warranty service shall be borne by Purchaser. No action to enforce this warranty shall be commenced after expiration of the warranty period.

CARE AND MAINTAINANCE:

It is the Purchaser's responsibility to perform the care, maintenance and assure correct load distribution as outlined in the OBI/Conqueror Owner's Manual. Other, separate manuals outline additional component care and maintenance. Please review all manuals supplied with your unit and if necessary, contact the Dealer you purchased your camper from if you have questions. Any damage to the vehicle as a result of the Purchaser's failure to perform such care, is not covered by OBI/Conqueror Corporation.

PARTS AND DESIGN CHANGES:

OBI/Conqueror Corporation may make parts and design changes from time to time without notice and repair and replacements may be made with new or different parts. OBI/Conqueror Corporation reserves the right to make changes in the design or material or its products without incurring any obligation to incorporate such changes in any product previously manufactured.

2 OBI CONQUEROR CORP. 2021 ALL RIGHTS RESERVED







You and any other user of OBI/Conqueror Corporation products shall not be entitled to any consequential or incidental damages, including without limitation, loss of use of the unit, inconvenience, lodging, damage to personal property, alternate transportation, phone calls, meals, lost income or earnings.

WARRANTY REGISTRATION:

Your warranty registration records should be completed and delivered to the manufacturers of component parts. OBI/Conqueror Corporation product warranty registration form must be returned to OBI/Conqueror Corporation within thirty (30) days of your taking delivery of your OBI/Conqueror product. Your OBI/Conqueror warranty will not be registered unless the warranty registration is completed and mailed to OBI/Conqueror Corporation. Failure to file this warranty registration can cause you delays in obtaining the benefits of your OBI/Conqueror Corporation Limited Warranty.

DISCLAIMER OF CONSEQUENTIAL & INCIDENTAL DAMAGES

The original consumer purchaser of this camping trailer and any person to whom this unit is transferred, and any person who is an intended or unintended user or beneficiary of this unit, shall not be entitled to recover from OBI/Conqueror Corporation or any consequential or incidental damages.

OWNER ASSISTANCE

Your continued confidence and goodwill are important to us at OBI/Conqueror Corporation as is maintaining a good relationship with our dealers. OBI/Conqueror Corporation recognizes that there may be occasions when a warranty or service problem is not handled to your satisfaction. We encourage you to attempt to rectify the situation by discussing the situation with your local dealership management; if after this your problem is not resolved to your satisfaction, we welcome you to contact us at the below address. We will provide our recommendations for an agreeable solution to our authorized dealers.

THIS WARRANTY GIVES YOU SPECIFIC LEGAL RIGHTS AND YOU MAY ALSO HAVE OTHER RIGHTS, WHICH VARY FROM STATE TO STATE.

LODGING A CLAIM

All warranty claims can be lodged by contacting your dealership.

If you have any further questions relating to warranties, or are unsure about any aspect of this section, then please contact us at:

Phøne: 877-949-4226

Email: info@obicamper.com









READY TO SET UP YOUR GRAVELER?

[DUE TO ITS COMPACT AND EASY TO USE DESIGN SETTING UP YOUR GRAVELER IS SIMPLE.]

⊐ \$T\$P\$] - 3 [INITIAL SET UP]

1. WHEN ARRIVING TO YOUR DESIRED CAMPING LOCATION BEGIN BY LOOKING FOR THE MOST FLAT PIECE OF LANO YOU CAN FINO. Ensure you have sufficient space around all sides of the camper if you plan to use the expandable awning.

2. ONCE YOU FIND A SUITIABLE PLACE TO SET UP CAMP CHOCK YOUR WHEELS, ENGAGE THE EMERGENCY BRAKE, AND MOVE ON TO STEP 3

3. AFTER THE WHEELS HAVE SAFELY BEEN CHOCKED BEGIN THE PROCESS OF DISCONNECTING YOUR MCHITCH AUTO COUPLER.

- DISCONNECT ELECTRICAL CONNECTIONS
- DISCONNECT SAFETY CHAINS
- REMOVE THE CLIP FROM THE SAFETY LOCKING PIN THEN REMOVE THE PIN FROM THE COUPLER
- LIFT THE RELEASE LEVER ON THE COUPLER THEN PROCEED TO SLOWLY MOVE THE TOW VEHICLE FORWARD UNTIL COMPLETELY DISCONNECTED FROM THE COUPLER.

_____ STEP 4 - 9 (ROOF TOP TENT SET UP)

4. TO BEGIN THE SET UP OF YOUR ROOFTOP TENT START BY UN-FASTENING THE TWO BUCKLES ON THE UNDERSIDE OF THE TENT ON THE RIGHT SIDE. These two straps hold down the shell of the tent.

5. ONCE THE STRAPS HAVE BEEN UNFASTENED PUSH UPWARD ON THE LIFT ASSISTED TENT SHELL UNTIL IT IS IN IT FULLY LOCKED UPWARD POSITION. After reaching a certain degree of lift the shell will automatically open all the way.

6. AFTER THE TENT SHELL HAS BEEN LIFTED REACH INSIDE OF THE TENT AND GRAB THE TELESCOPING LADDER AND PULL TOWARDS YOU. This will fold out the over-hanging bed platform of the tent.

7. NEXT, EXTEND THE TELESCOPING LADDER TO THE GROUND ENSURING THE LADDER IS LOCKED IN PLACE AND THE PLATFORM IS LEVEL. The ladder acts as a support for this section so ensuring it is locked in place is crucial to a successful set up.

8. LOCATE THE 4 SILVER WINDOW SUPPORT RODS INSIDE OF THE TENT. THESE RODS HAVE A HOOK ONE END AND A RUBBERIZED CAP ON THE OTHER. ON BOTH SIDES OF THE WINDOW FLAPS LOCATE THE CIRCULAR METAL GROMET. THESE GROMET HOLES HOLD THE HOOKED END OF THE ROD. ON THE TENT SIDE, BENEATH EITHER WINDOW YOU WILL FIND A POCKET HOLE THESE HOLES HOLD THE CAPPED END OF THE ROD. START BY ATTACHING THE HOOKED END OF THE ROD IN THE GROMET HOLE THEN THE CAPPED END OF THE ROD INTO THE POCKET HOLE. THESE RODS ARE DESIGNED TO BEND AND CREATE TENSION ON THE FLAP. THIS CAN BE SEEN IN THE PHOTO BELOW.

